


L & E Fabrications, LLC Vacuum Booster Eliminator Kit

Step 1




STEP 1

Remove the two nuts to remove the master cylinder from the vacuum booster.


STEP 2

Remove the pedal push clip from the booster shaft by loosening the nut and pivot pin retaining clip.

Step 2




Step 3



STEP 3


Remove the 4 nuts from the vacuum booster and remove booster.



Step 4

STEP 4


Install the master cylinder on the aluminum plate using shorter 2 bolts and locking flange nuts.



Step 5

STEP 5

Install the aluminum plate with the master cylinder using 4 longer bolts and locking flange nuts.



Step 6

STEP 6

Install the new push rod using the lock nut, the pedal clip and the pin assembly.